



TERRAPIN X

CONNECTING


your TERRAPIN X to the GARMIN Foretrex® 701




- By pressing and releasing the push button of your TERRAPIN X you turn on the device
- You will now see the digital aiming reticle in the display of your TERRAPIN X



- Press and release the push button of your TERRAPIN X three times in quick succession to enter the Bluetooth menu
- In the display you will see the last saved setting. This can either be "OFF", "APP", "hEST" (for KESTREL) or "tdH"



- Toggle through the options by pressing and releasing the push button of your TERRAPIN X until you reach "tdH"



- Confirm this setting by pressing and releasing the push button three times in quick succession
- As confirmation four dashes ("----") will appear in the display of your TERRAPIN X
- Besides the electronic aiming reticle you will now also see a flashing Bluetooth symbol in the display of your TERRAPIN X. This signifies that the TERRAPIN X has entered the pairing mode



- In the menu of the GARMIN Foretrex® 701 navigate to “CONNECT” by clicking “PAGE” and the arrow buttons
- To enter the “CONNECT” menu press “ENTER”



- In the "CONNECT" menu scroll down to "VECTRONIX"
- Choose "SEARCHING" and press "ENTER"



- Choose “SEARCH FOR NEW” and press “ENTER”
- Select your TERRAPIN X and press “ENTER” to connect it to the GARMIN Foretrex® 701

When a connection is established, the TERRAPIN X transmits range to the GARMIN Foretrex® 701. Using this data, the GARMIN Foretrex® 701 calculates an accurate firing solution.

VISIT US ON INSTAGRAM, YOUTUBE OR ON OUR WEBSITE
www.terrapin-x.com #myTPNX

